


## The wedi world of systems


Superior guaranteed safety with unrivalled ease of use



- 01 Flush to floor showers from the wedi Fundo range in various designs and sizes and with different drain technology
- 02 Innovative extension options such as the wedi Fundo Riolito Discreto visual wall drain combined with bench and tray element or retention wall
- 03 Shelf and niche designs of all kinds
   from modular prefabricated elements to individual constructions
  with the wedi building board
- O4 Stable partition wall solutions in different designs, e.g. as a shower screen, room divider or as a privacy screen
- O5 Stylish bathroom furniture from the wedi Sanbath design range as prefabricated elements for wash stands, baths, showers, etc.
- O6 Stable floor applications with the wedi building board optimised for renovations, e.g. as a carrier solution
- 07 Individual wash stand solutions thanks to the wide range of wedi building boards in almost every conceivable design
- OB Prefabricated elements for cladding pipes and baths or as WC installation system covers, e.g. the wedi
- OP Creative loungers and benches in a range of differing formats and configurations from the wedi Sanoasa design and wellness range
- 10 Safe working tools for the systematic sealing, adhesion, decoupling and impact sound deadening board – abP, CE and ETA certified
- wedi Mensolo U angled unit Create a perfect useful space for body care products, hand towels or decoration with the wedi Mensolo angled units.







## Contents

- Premium brand wedi
- Customer benefits
- 24
  - 01 With a large shower
  - 02 The bench in the shower

  - 04 The practical shower bath

  - Building board working principle
    - wedi building board 4 and 6 mm
    - wedi building board 20 mm • wedi building board 12.5 mm
    - wedi building board XL and XXL
    - wedi Mensolo
    - wedi I-Board
    - wedi building board Construct
    - wedi Moltoromo
    - wedi Bathboard
    - wedi building board Vapor
    - wedi Niches

    - wedi building board construction

- 84

  - wedi Fundo Integro

  - wedi Fundo Ligno
  - wedi Fundo Primo Easy Set
  - wedi Fundo Plano Linea
  - wedi Fundo Riolito neo
  - wedi Fundo Riolito

  - wedi Shower-Kits
  - wedi Fundo Top

  - Channel covers and grates

  - - wedi Fundo floor element/drain technical specifications
    - wedi building board technical specifications
    - Sealing and separation in the wedi system



## Building, renovating and designing with the wedi system

## For over 30 years

When my father Helmut Wedi founded wedi GmbH in 1983, he had one clear goal in mind: to develop high-quality and above all practical solutions for the trade which provide real added value to every wedi customer. Over the last 34 years, this goal has turned into a mission, a philosophy even, which has a decisive impact on the daily work of both me and my employees.

Due to our proximity to the trade and our widespread presence, we are consistently able to respond to our customers' wishes on a rapid and straightforward basis. In this context, the system safety that we guarantee as well as the straightforward and time-saving processing take centre stage. Our daily experiences and the feedback we receive from our customers provide the basis for the further development of our products, systems and services.

Today, building, renovation and design work in the modular wedi system therefore means far more than just the well-known wedi building board. It stands for complete solutions in the challenging wet room as well as numerous services in the areas of sales support and application technology which have made wedi into a premium brand for the realisation of bathroom and wellness areas.



Managing Director of wedi GmbH



# We only use the best materials for the best systems

Waterproof

The blue XPS core is 100% waterproof and still functions if it becomes damaged.

2 Stable

The cement-coated surface forms an incredibly strong and stable base for adhesive thanks to the integrated fabric.

03 **Heat insulating** 

All of our building board systems provide fantastic insulation, save energy costs and provide long term protection against mould and fungus. 04 Tested &

approved system

The ETA and abP\* test certificates document the fact that wedi products are certified sealing systems for wet rooms. For increased reliability with shorter installation times.

05 Low-emission

The products fulfil the requirements of the AgBB [German committee for Health-related Evaluation of Building Products] scheme (D) as well as the Belgian and French VOC regulations. The A+ here stands for exceptionally low emission, non-hazardous product systems.



Customer advantages
Guaranteed quality,
practically-oriented

and individual

## Specialist retailers

- Safe, high quality products from the brand manufacturer wedi
- No complaints or compensation claims with professional installation
- Completely aligned product systems with abP, ETA and CE approval
- Straightforward and safe processing reduces the sources of error for your customers
- Critical and complex work steps are already integrated in the product system
- Expert advice and technical support from wedi application technology
- The properties of the modular wedi system save on additional and time-consuming sealing measures

## Tradesmen

- Sophisticated systems save time, money and stress
- 100 % security with the manufacturer's product guarantee covering all components of the entire wet area
- Modular system allowing flexibility and variety in use thus creating additional business
- Innovative product solutions offering competitive advantages
- Perfect surface for challenging tiling work
- Professional support from wedi expert advice from our technical sales managers, internal sales and marketing departments as well as technical support from our application technology department

## Contractors/planners

- Safe product systems (abP/ETA/CE) for renovation work in bathrooms and wet rooms
- Sustainable protection against damp and mould, especially in wet areas
- Clear reductions in energy costs thanks to the thermal insulation integrated in the system
- Technical support from wedi application technology team competent, personal and quick







# So that safety is guaranteed in your system



The CE labelling of the wedi products documents their tested and approved use as a sealing system for wet rooms.



Systems from wedi are labelled with the French VOC classification. A+ stands for exceptionally low emission, non-hazardous product systems.



The wedi product systems satisfy the construction guidelines and regulations that are valid in England, Wales, Northern Ireland and Scotland.



The modular system solutions from wedi have a wide range of differing technical building approvals and test certificates.



With the Silver Architects' Darling award in 2013, wedi was honoured as one of the most popular German manufacturers in the construction sector.



The barrier-free wedi products have been tested, assessed and certified for their conformity by the DIN CERTCO organisation for conformity assessments.





The wedi product systems have been technically tested and labelled in France by the CSTB (Centre scientifique et technique du bâtiment).



When manufacturing its products, wedi uses certified green electricity from renewable energies.



The wedi construction systems are labelled with the leading Finnish emissions classification. In this context, M1 stands for the highest quality.



The Norwegian test seal, which corresponds to the European requirements, certifies the high technical quality of the wedi product systems.



The wedi quality management and the high product quality are labelled with the Finnish VTT test seal.



The MK test seal qualifies wedi products for use in Denmark in accordance with the country-specific guidelines, norms and standards.

## Self-explanatory assembly instructions and videos

Every wedi system solution comes with several attractively designed sets of work instructions in digital and printed format. With the help of self-explanatory step-by-step tutorial videos, internationally usable installation guides and detailed technical documentation, the success of every installation is assured.









## Technical training

A comprehensive range of technical and practical training on the wedi premises, construction site or at a wedi specialist retailer allows for the optimal use of the modular wedi systems. The wedi applications technology team and sales staff are also available offering professional and technical support.















## The **10-year quality guarantee** on the entire range


With the extended guarantee on all products and systems, wedi is setting new standards when it comes to quality leadership. You can find all the relevant information about the new guarantees and the corresponding conditions at: www.wedi.eu



# So that you stand out from the competition

## A variety of designs in the modular system construction

The wide range of individual products and complete systems enables an unrivalled variety of designs. This also enables the wedi customers to extend their area of business. From the floor element to the wall and ceiling cladding, from the shower to the wash stand and the bath – the complete bathroom from one single source.



## Highest quality of workmanship

The combination of professional work and high quality product systems offers a first rate and secure quality of workmanship, and enables wedi customers to gain huge business advantages in comparison with the competition.




## Applications technology

Do you have any questions about the wedi products or their applications? Don't worry! The application technology team and your wedi sales representative are always available for advice and assistance – from the initial idea, through the optimum planning, to the final result. On-site assistance at the building site is also available.



## Innovative product systems

At wedi, innovation stands for the development of clever solutions to common construction problems; wedi is always at the cutting edge in terms of their design and technology. Planners and tradesmen, for instance, benefit from the flush to floor showers with their especially low construction heights, the drain technology that is integrated in the system, the visual wall drain, the close-to-wall linear drainage and the varied choice of different design grates.



## So that your time is not wasted

## Proven in a direct comparison

The partition wall solution with the wedi XXL building boards: Less material to transport • Shorter working times • Fewer work steps • Tiling possible after just 1 day • Wall construction and sealing in a single work step • Extremely robust and 100% watertight • Fully functional, even with potential damage – in contrast to brushable seals

## Conventional masonry Spirit level Pencil Stirrer for mortar and plaster Hand saw for stones Trowel Smoothing trowel / spatula Cutter Drill for wall anchor

Products	Quantity	Processing	Drying
Stone Porous concrete	16 pcs., 18 kg	144 min.	1 day
Adhesive	3 kg	64 min	1 day/mm
Fabric	5 m², 0,5 kg		
Reinforcing mortar	30 kg	04 111111.	3 – 4 days
Wall anchor	5 pcs.	10 min.	-
Composite sealing element	3 kg	20 min.	1st layer: 2 h 2nd layer: 4 h
	54,5 kg	238 min.	5 days

Sources for determining the time, suggested tariff for the North Rhine Tiling and Paving Trade (default values), calculation aid fitout – façade – conversion

wedi building board XXL					
<ul> <li>Spirit level</li> <li>Pencil</li> <li>Cutter, jig-portable ci</li> <li>Cartridge of</li> </ul>	rcular saw				
Products	Quantity	Processing	Drying		
wedi BA XXL 50 mm	1 pcs., 13,8 kg	30 min.	1 day		
wedi 610	310 ml, 0,5 kg				

14,3 kg

30 min.

1 day


## Punctual deliveries

Whether it is individual products or complete systems – wedi delivers every order to the requested location. The safe and above all punctual delivery is furthermore guaranteed by our subsidiary company, wedi Logistik GmbH.

## Straightforward workmanship

The interfacing system elements guarantee the efficient completion of the installation work in the shortest time. wedi solutions offer safety, save time, money and stress.





## Work steps are factory-integrated in the system

Labour-intensive installation steps, such as the individual construction of a slope board or the complex and possibly risky sealing of inlets and drains always cost a lot of working time. wedi brings the critical and complex work steps directly into the product system: such as the watertight and optionally integrated drain technology, the factory-integrated slope boards or the wide range of specially developed extension and sealing tools.



# So that you can complete your work without worry

## Lightweight construction

All product systems from wedi are designed for straightforward, easy and low-dust workmanship to protect the installer. Thanks to the exceptionally light construction, heavy duty and exhausting lifting at higher floor levels is also avoided.

## One phone call is enough

If, despite the high quality of the wedi products, a fault should occur, wedi can guarantee the rapid and straightforward handling of any concerns with its excellently trained personnel.





## One key personal contact for sealing, technical matters & design

A further added benefit that wedi customers enjoy is the assistance they are offered from a single personal contact: from the initial renovation idea, through the selection of systems and the alignment of the technical details, to the installation.







# So that your project gains the best exposure

## **Customised POS systems**

wedi retail partners keep wedi products ready for you on site which allow you to construct a system at any time without any extensions or delays. The wedi POS systems are individually customised to the requirements of the local conditions, to the equal, shared benefit of the workman and retailer. The retailer is able to present the products in an attractive, sales-supporting way, while the workman gains the best possible overview of useful system products, example applications and appropriate working aids.



## Sales and advertising tools

Sales support, marketing instruments, presentation documentation, vehicle graphics and much more – all wedi customers are able to access a wide selection of individual communication methods which are consistently available online at www.wedi.eu.



## All important information on the web: www.wedi.eu

How do you work with the product? What accessories are required? Does wedi also offer compatible system components? With the internet platform, wedi customers receive rapid, straightforward answers to all of their questions regarding the premium brand wedi, as well as access to helpful tools at the same time.



## Bathroom systems Ideas, design and solutions

The bathroom systems from wedi stand out thanks to their straightforward, safe and modular construction, without being limited in terms of their variety of designs. Furthermore, all wedi products are certified for use in wet rooms according to German and European standards and are 100 % watertight.

On the following pages you will find a selection of bathroom design concepts and wedi system configuration examples which demonstrate how easy the shower solutions, wall and floor applications, shelf and wash stand solutions are to achieve with wedi.



03

04

05


D

rocessing

undo processing

lecuriology

Products





## With a large shower

Large-scale shower solutions are becoming increasingly popular in modern bathrooms. If the space available and the room allows it, benches, tray options or visual partition walls can also be realised with wedi.



02

03

04

05

03

ocessing

Fundo processing

Technology











## System configuration for shower situation

The wedi Fundo floor elements aren't only available in a wide range of formats and drain options, they can also be extended in all directions as required.


## Products used

- 1 wedi Fundo Primo shower element, in this case with offset point drainage
- 2 wedi Fundo drain in this case with a horizontal DN 50 drain including drain cover
- 3 wedi building boards for designing wall and niche solutions
- 4 **NEW:** wedi Niches for the creation of additional tray elements in the shower and bath
- 5 wedi 610 adhesive and sealant for the watertight adhesion of joints
- 6 wedi Tools reinforcement tape for reinforcing joints

Stable, decoupling, insulating and height-compensating – the wedi building boards are also ideal for floor-level tiling, and thanks to their different strengths, they are perfectly suited to private renovation work.

## Products used

- wedi building boards as thermally insulating flooring
- 2 wedi 610 = adhesive and sealant for the watertight adhesion of joints
- 3 wedi Tools reinforcement tape for reinforcing joints
- wedi Nonstep Plan impact sound deadening board with 14db of sound insulation under ceramic flooring







## System configuration for WC solution

wedi I-Board is a prefabricated installation element for the cladding of wall-mounted WCs. With a width of 1,200 mm, it can be easily adapted to individual requirements. Despite being light weight, it is extremely strong and stable.

## Products used

- 1 wedi I-Board prefabricated cladding for wall-mounted WCs,
  Alternative application: stick with wedi 610 on stud frames
- 2 wedi Tools washers with self-tapper screws for attaching to the carrier sub-structure
- 3 wedi Tools reinforcement tape for reinforcing joints



## System configuration for bench and tray elements

The high individual stability of the wedi building boards as well as the simplicity of cutting them to the required dimensions down to the last millimetre enables the realisation of almost any design in the wet room.

## Products used

- wedi building boards for configuring, cladding and connecting construction components
- 2 wedi 610 adhesive and sealant for the watertight adhesion of joints
- 3 wedi Tools reinforcement tape for reinforcing joints




02



## The bench in the shower

With the modular wedi systems, almost all design ideas can be realised in a straightforward way. For example, here is a wedi bench with an integrated wall drain in the shower, or an illuminated ledge solution above the wash stand.



03

04

05

UJ

Building board pro

Fundo processing

Technology

roducts








## А

## System configuration for wall and shelf solution

Thanks to the variable use of the wedi building boards, it is possible for wall cladding, wall installations and shelf solutions to be created on a simple and straightforward basis.

## Products used

- 1 wedi building boards for designing wall and niche solutions on a carrier construction
- 2 wedi 610 adhesive and sealant for the watertight adhesion of joints and the building board on stud frames
- 3 wedi Tools reinforcement tape for reinforcing joints
- 4 wedi Tools fixings set for the stable screw-attachment of bathroom furniture



#### System configuration for complete shower solution

This example shows the variety of the modular wedi systems very clearly. The floor level shower element with integrated slope board, the visual wall drain under the bench, the wall cladding and the free standing, stable partition wall are combined in one system. In this case, the wedi Mini Max drain version requires an installation depth of only 99 mm, including the thickness of the shower element.

#### Products used

- 1 wedi Fundo Riolito the shower element with linear drainage
- 2 wedi Fundo Riolito drain in this case with a horizontal Mini Max DN 40 drain
- 3 wedi Sanoasa bench 3 bench, rounded
- 4 wedi Fundo Riolito Discreto the visual wall drain, in this case, integrated in the carrier element of the bench

- 5 wedi building boards as free-standing partition wall and for the cladding of wall surfaces
- 6 Optional: wedi Nonstep Pro Sound insulation mats for water noise insulation under wedi Fundo floor elements
- 7 **Optional:** wedi edge insulation strips Sound insulation for the area between wedi Fundo floor elements and the wall
- 8 wedi 610 adhesive and sealant for the watertight adhesion of joints
- 9 wedi Tools reinforcement tape for reinforcing joints
- 10 wedi Fundo sealing set for sealing of the perimeter of Fundo floor elements when connecting to adjacent surfaces



02

03 04

05

Building board processing



#### The unconventional shower tray


The perfect interplay of the modular wedi system also facilitates unconventional solutions. For instance an individual wash stand which functions as a shower tray at the same time is equally as possible as the cladding of the bath.



Building board processing







#### А

#### System configuration for bath cladding

The prefabricated wedi Bathboard bath cladding has a 20mm thickness and can be used for almost every bath format. Thanks to the height-adjustable feet, during the installation uneven areas of up to 10 cm can be safely levelled in bare concrete or screed. This makes the control frame superfluous.

- 1 wedi Bathboard for the height-adjustable cladding of the head and side panels
- 2 wedi 610 adhesive and sealant for the watertight adhesion of joints
- 3 wedi Tools reinforcement tape for reinforcing joints



#### System configuration for shower situation

The high individual stability of the wedi building boards as well as the simplicity of being able to cut them to the required dimensions enable the individual construction of creative wash stand and shower solutions.

The wedi Fundo Plano Linea is also integrated in this example system. With its factory-integrated drain technology, the system measures just 70 mm and is a special highlight for bathroom renovations.

- wedi building boards of for the exacting design of wash stand solutions
- 2 **Optional:** wedi Nonstep Pro Sound insulation mats for water noise insulation under wedi Fundo floor elements
- 3 Optional: wedi edge insulation strips Sound insulation for the area between wedi Fundo floor elements and the wall
- 4 wedi 610 adhesive and sealant for the watertight adhesion of joints
- 5 wedi Tools reinforcement tape for reinforcing joints
- 6 wedi Fundo Plano Linea shower element with integrated drainage technology (linear drainage)
- 7 wedi Fundo sealing set for sealing of the perimeter of Fundo floor elements when connecting to adjacent surfaces




For work and processing guidelines, refer to www.wedi.eu – product overview starting from page 132



#### The practical shower bath

Small bathrooms can also be renovated quickly and easily with the modular wedi systems: WC and wash stand installed on a wall element as well as the practical shower with a self-supporting partition wall under the apex.











#### А

#### System configuration for the retention wall

wedi building board systems can be attached to existing carrier constructions with ease. Whether attached using 610 adhesive or screw connections, as a WC / wash stand retention wall installation or for the cladding of hoses and pipelines – they can be freely combined at all times and can be configured so they are flush with each other.

- 1 wedi building boards for the cladding of adjoining areas
- 2 wedi 610 adhesive and sealant for the watertight adhesion of joints and as assembly adhesive
- 3 wedi Tools reinforcement tape for reinforcing joints
- 4 wedi Tools sealing gaiter flexible sealing for pipelines
- (5) wedi Tools cavity dowels set for the attachment of hooks, hand towel holders or small hanging items of furniture




#### System configuration for shower situation

Thanks to the pre-fabricated drain, the entire system is a mere 65 mm. This wedi solution is absolutely unbeatable in renovation work, such as old building renovations, where every millimetre counts.

#### Products used


В


- wedi Fundo Plano extremely flat flush to floor shower element with integrated drain technology (point drainage)
- 2 wedi building boards for constructing shower screens
- ③ **Optional:** wedi Nonstep Pro Sound insulation mats for water noise insulation under wedi Fundo floor elements
- 4 Optional: wedi edge insulation strips Sound insulation for the area between wedi Fundo floor elements and the wall
- 5 wedi Fundo sealing set for sealing of the perimeter of Fundo floor elements when connecting to adjacent surfaces
- 6 wedi 610 adhesive and sealant for the watertight adhesion of joints
- 7 wedi Tools reinforcement tape for reinforcing joints



#### The complete corner shower

The majority of all showers in private bathrooms are positioned in the corner of the room. In this context, the interplay of the wall configuration including possible niche solutions and the appropriate flush to floor shower element and drain technology plays a key role. wedi systems stand out thanks to their system safety and simplicity of management and installation












#### А

#### System configuration for shower elements

wedi floor elements aren't only available in a wide range of formats and drainage versions, they can also be extended in all directions as required.

- 1 wedi Fundo Ligno flush to floor shower element for wooden beam joists
- 2 wedi Fundo drain integrated into the suspended timber floor
- 3 wedi building boards for the construction of shower walls
- 4 wedi Subliner Dry & Flex crack-bridging sealing and decoupling membrane
  wedi Tools sealing tape for secure sealing of corner, connecting and butt joints and intersections
- 5 wedi 610 adhesive and sealant for the watertight adhesion of joints
- 6 wedi Fundo sealing set for sealing of the perimeter of Fundo floor elements when connecting to adjacent surfaces
- 7 wedi Tools reinforcement tape for reinforcing joints





#### System configuration for shower screen solution

Whether as a retention wall on a carrier construction or installed directly on the surface of the wall, the wedi building boards are the ideal basis for tiles and also facilitate individual solutions such as shelving and niches.


- 1 wedi building boards for designing wall and niche solutions
- 2 **NEW:** wedi Niches for the creation of additional tray elements in the shower and bath
- 3 wedi 610 adhesive and sealant for the watertight adhesion of joints
- 4 wedi Tools reinforcement tape for reinforcing joints



# wedi building boards:

From product to system

Bathrooms can be completely or partially renovated in a very short space of time with the watertight building board solutions from wedi. The base material also offers real added value, such as thermal insulation, lightweight construction or unlimited compatibility in the complete system. You can find a selection of the possible uses and their technical execution on the following pages. wedi building boards — the right solution for every requirement.




## Building board 4 & 6 mm All types of substrate levelling



- 1 wedi building boards for designing wall solutions
- 2 wedi 610 adhesive and sealant for the watertight adhesion of joints
- 3 wedi Tools reinforcement tape for reinforcing joints

#### Ultra-thin and usable anywhere

When old bathrooms in need of renovation are being modernised, there is often the question of how to deal with the old wall coverings, e-g- half height tiled walls. wedi building boards offer a simple solution here. They are usually used in thickness of 4 or 6 mm since these can be mounted flush with the old tiling and create a neat, even surface. Also used as packing/levelling strips under mosaic accent strips, the 4 mm thick wedi building boards can be very helpful on a wall with large format tiling.



Attach the building boards across the full surface with tile adhesive.



Seal the joints with wedi 610 and apply wedi Tools joint reinforcement tape.



Finally tile, or alternatively apply plaster.



## Building board 20 mm For uneven surfaces




- 1 wedi building boards for the construction of wall solutions on uneven surfaces
- 2 wedi Tools sealing tape for secure sealing of corner, connecting and butt joints and intersections
- 3 wedi Tools metal dowels for affixing building boards to walls

#### The ideal base for tiles

If, in bathrooms needing renovation, the old surfaces are not or are only partially load-bearing, wedi building boards with a thickness of 20 mm are used in combination with wedi Tools metal dowels. This eliminates the need for the cost-intensive, extensive effort of making the old surfaces load-bearing.



Punch or mark holes on the board. Apply medium-bed mortar where the holes are marked.



Gently put up the building boards and align with a spirit level. Wait until the mortar has hardened and drill the holes in the wall.



Place wedi Tools metal dowels in the holes and hammer in after the mortar has fully dried.




### Building board 12.5 mm For plasterboard transitions



- 1 wedi building boards for designing wall and partition wall solutions
- 2 wedi Tools reinforcement tape for reinforcing joints
- 3 wedi 610 adhesive and sealant for the watertight adhesion of joints as well as for the assembly of the building panel on the stand
- 4 wedi Tools metal dowels for affixing buildings boards to walls

#### Precise transitions to plasterboard


12.5 mm thick wedi building boards are an extremely practical continuation which attach entirely flush to plasterboard panels in the wet areas and areas with water spray in bathrooms. In contrast to conventional plasterboard panels, they are 100% watertight in combination with the wedi Tools sealing tape without any additional coating, and at the same time are thermally insulating and thus reduce the formation of condensation.



Align the wedi building board flush with the plasterboard panel.



Apply wedi Tools joint reinforcement tape to the joints.



The tiling or plastering can then be carried out.



# Building board XL and XXL Free-standing partition walls




- 1 wedi building boards XL & XXL as free-standing partition wall, building board thickness 50 mm
- 2 wedi building boards for designing wall and niche solutions
- 3 wedi 610 adhesive and sealant for the watertight adhesion of joints
- 4 wedi Tools reinforcement tape for reinforcing joints

#### Free-standing and stable, without additional supports

The large-size wedi building boards are particularly notable due to their extraordinary widths of up to 1.20 m. As a result, they are not only ideal for use as free-standing walls, they also reduce the number of joint transitions and simplify installation enormously.



Simply position ...



... glue-seal and reinforce all joints ...



... and then tile, done!



# Mensolo L and U Shelves and cladding



- 1 wedi Mensolo L Prefabricated element for shelves and pipe cladding
- 2 wedi Mensolo U Prefabricated element for shelf solutions
- 3 wedi building boards for designing wall and niche solutions
- 4 wedi 610 adhesive and sealant for the watertight adhesion of joints
- 5 wedi Tools reinforcement tape for reinforcing joints

#### Versatile tray elements

The practical Mensolo prefabricated elements in L and U shapes can be used in a variety of ways. The elements are often used as shelf solutions or for pipe cladding. Subsequent surface design can be achieved either tiled or plastered.



Cut to the desired length...



... glue-seal, fix and reinforce ...




...tile, done!








# I-Board WC installation systems cover



- 1 wedi I-Board prefabricated cladding for wall-mounted WCs
- 2 wedi building boards for the cladding of adjoining areas
- 3 wedi 610 adhesive and sealant for the watertight adhesion of joints
- 4 wedi Tools reinforcement tape for reinforcing joints

#### Unpack. Install. Finished!

wedi I-Board is a prefabricated installation element for the cladding of wall-mounted WCs. With a width of 1200 mm, it can be easily adapted to individual requirements. Despite its light weight, it is extremely strong and stable. It is connected to the carrier element either with wedi 610 adhesive and sealant or alternatively with the wedi Tools washers and drywall screws.



Cut accurately ...




... glue or screw and reinforce ...



... tile, done!




### Building board Construct Round design




- 1 wedi building boards Construct shapeable building board for individual configuration
- 2 wedi building boards for the exacting design of wash stand solutions
- 3 wedi 610 adhesive and sealant for the watertight adhesion of joints
- 4 wedi Subliner Dry & Flex crack-bridging sealing and decoupling membrane wedi Tools sealing tape for secure sealing of corner, connecting and butt joints and intersections
- 5 wedi Tools reinforcement tape for reinforcing joints

#### As flexible as necessary, as robust as possible

Regardless of whether it is narrow radii or semi-circular solutions, thanks to its factory-cut longitudinal and traverse sections, the Construct building board gives free rein to every idea.



Assemble in the correct shape ...



... reinforce and seal ...



... leave to set, done!




### Moltoromo Creative wall solutions




- 1 wedi Moltoromo the modular system for any number of wall designs
- 2 wedi 610 adhesive and sealant for the watertight adhesion of joints
- 3 wedi Tools reinforcement tape for reinforcing joints

#### The only limit is your imagination

With the modular wedi Moltoromo system, versatile wall configurations can be created for different bath and wellness applications. Round shapes, angled solutions or sinuous lines, for example, can be installed quickly and easily. Decoration with tile or plaster has barely any limitations.



Apply wedi 610 adhesive and sealant to the Moltoromo elements' grooves.



Connect the individual Moltoromo elements with the help of the tongues supplied.



Seal the open joints with wedi 610 adhesive and sealant, and reinforce the joints with wedi Tools reinforcement tape.



## Bathboard Bathtub cladding



- 1 wedi Bathboard for the height-adjustable cladding of the head and side panels
- 2 wedi building boards for the cladding of adjoining areas, e.g. as a retention wall
- 3 wedi 610 adhesive and sealant for the watertight adhesion of joints
- 4 wedi Tools reinforcement tape for reinforcing joints

#### Fits any wall like a glove

The prefabricated wedi Bathboard bath cladding has a thickness of 20 mm and can be used for almost every bath format. Thanks to the height-adjustable feet, uneven areas of up to 10 cm during the installation can be safely levelled in bare concrete or screed. This makes the control frame superfluous.







... glue and reinforce joints ...



... align, done!




### Building board Vapor Excellent moisture protection




- 1 wedi building boards Vapor Special building board with integrated vapour barrier
- 2 wedi Sanoasa Bellina bench
- 3 wedi Tools sealing tape for secure sealing of corner, connecting and butt joints and intersections

#### The ideal vapour barrier

The wedi Vapor building board has been specially designed for interior applications where very high levels of humidity are a constant factor and as such may require a vapour barrier when installing interior thermal insulation for construction reasons. This applies in particular for the internal walls of swimming pools, steam baths and communal shower facilities.



Attach the wedi Vapor building boards across the full surface with tile adhesive.



Seal the joints with wedi Tools sealing tape bedded in a layer of Epoxy tile adhesive and quartz sand.



The tiling or plastering can then be carried out.



## Niches Practical storage elements




- 1 wedi building boards for the installation of wall solutions on a supporting structure (metal or wood stud frame)
- 2 **NEW:** wedi Niches for the creation of additional tray elements in the shower and bath
- 3 wedi 610 adhesive and sealant for the watertight adhesion of joints as well as for the assembly of the building panel on the stand

#### The perfect mix of design and function

The wedi niches are both practical and aesthetically pleasing. Their large form underlines the extravagant character of any bathroom. In addition, they offer extra space for a multitude of shower products or individual decorating ideas. And the best thing: they are available in a variety of formats and are compatible with the standard wedi system solutions.



Cut an appropriate recess in the wedi building board.



Apply wedi 610 adhesive and sealant to the niche and insert the niche.



Add wedi 610 adhesive and sealant and wedi Tools joint reinforcement tape all round it.




### Sanoasa benches Convenient shower solution



- 1 wedi Fundo Riolito neo the flush to floor shower element with close-to-wall linear drainage
- 2 wedi Sanoasa bench 1 bench, straight
- 3 wedi Fundo Riolito Discreto the visual wall drain, in this case, integrated in the carrier element of the bench
- 4 wedi building boards as free-standing partition wall and for the cladding of wall surfaces
- 5 wedi 610 adhesive and sealant for the watertight adhesion of joints
- 6 wedi Tools reinforcement tape for reinforcing joints

#### A fantastic variety of design options


Convenience means something different for everyone, but the feeling of relaxation when sitting under the shower with the water droplets massaging your back is a very pleasant experience for all. The wedi Sanoasa benches offer plenty of space for relaxation and for comfortable personal care.



Cut the support element for the Sanoasa bench to the desired size.




Glue the individual components with wedi 610 adhesive and sealant.



Finally, apply wedi Tools joint reinforcement tape to the joints.



## Building boards construction Individual construction




- 1 wedi building boards for the individual construction of bathroom furniture and for cladding walls
- 2 wedi 610 adhesive and sealant for the watertight adhesion of joints
- 3 wedi Tools reinforcement tape for reinforcing joints
- 4 wedi Tools connector as a connecting and mounting element for building boards

#### Bathroom furniture that no-one else has

The fact that wedi building boards are much more than simple supports for walls and floors will become clear when you look at the individual design possibilities. The 30 to 80 mm thick building boards are perfectly suited for the construction of tileable elements such as washbasins, shelves or tray elements.



Cut the building board to the desired dimensions and install with wedi Tools connectors and wedi 610 adhesive and sealant.



Apply wedi Tools joint reinforcement tape to the joints.




Tiling of the bathroom furniture can be carried out.




## wedi Fundo: Solid foundations, for well-founded reasons

Functionality and safety play important roles for flush-to-floor showers. That's why tradesmen have been putting their faith in the unique quality from wedi for decades. Simple, quick and safe – this is the best summary of the wide variety of possible applications. See for yourself on the following pages.





## Fundo Primo The classic type of point drainage




- 1 wedi Fundo Primo shower element, in this case with central spot drainage
- 2 wedi Fundo drain in this case with a horizontal DN 50 drain including drain cover
- 3 wedi Fundo sealing set for sealing of the perimeter of Fundo floor elements when connecting to adjacent surfaces
- 4 Optional: wedi Nonstep Pro Sound insulation mats for water noise insulation under wedi Fundo floor elements
- 5 Optional: wedi edge insulation strips Sound insulation and insulation for the area between wedi Fundo floor elements and the wall

#### Unbeatably simple, sunk in screed

For classic point drainage in the shower, wedi offers Fundo Primo floor elements in a wide variety of sizes. Whether square or rectangular, placed in the middle of the room or in they corner, the offer the ideal solution for every space and can easily be rounded out to form a complete shower area with the help of wedi building boards.



## Fundo Integro Standard-compliant complete system



- wedi Fundo Integro Flush-to-floor shower element with standard-compliant drain technology integrated in the factory
- 2 wedi Fundo Integro sealing corner for sealing the filled gap for the pipe connection
- 3 wedi Fundo sealing set for sealing of the perimeter of Fundo floor elements when connecting to adjacent surfaces
- 4 wedi Fundo Fino exclusive designer grate for point drainage

#### Point drainage with integrated drain


With a total installation height of just 90 mm, Fundo Integro is wedi's flattest flush-to-floor shower element with integrated drain technology which satisfies all of the relevant standards: 50 mm water trap height, 0.8 l/sec. drain capacity, at least 1.5% gradient preformed in the factory, made from 100% waterproof material, sealed ready for installation and installed in the blink of an eye.







## Fundo Plano 65 mm thin complete system



- 1 wedi Fundo Plano extremely flat flush to floor shower element with integrated drain technology
- 2 wedi building boards for constructing shower screens
- 3 wedi Fundo sealing set for sealing of the perimeter of Fundo floor elements when connecting to adjacent surfaces
- 4 Optional: wedi Nonstep Pro Sound insulation mats for water noise insulation under wedi Fundo floor elements
- 5 Optional: wedi edge insulation strips Sound insulation and insulation for the area between wedi Fundo floor elements and the wall
- 6 wedi 610 adhesive and sealant for the watertight adhesion of joints

#### Point drainage with integrated drain

Thanks to the pre-fabricated drain, the entire wedi Fundo Plano system is a mere 65 mm thin. This innovation is absolutely unbeatable in renovation work, such as old building renovations, where every millimetre counts. Perfection in renovation.



## Fundo Ligno Point drainage in suspended timber floors



- 1 wedi Fundo Ligno flush to floor shower element for wooden beam joists
- 2 wedi building boards for constructing shower screens
- 3 wedi Subliner Dry & Flex crack-bridging sealing and decoupling membrane wedi Tools sealing tape for secure sealing of corner, connecting and butt joints and intersections
- 4 wedi 610 adhesive and sealant for the watertight adhesion of joints
- 5 wedi Fundo sealing set for sealing of the perimeter of Fundo floor elements when connecting to adjacent surfaces

#### The embedded variant with zero installation height

The wedi Fundo Ligno was specially developed for use in old and new buildings with suspended timber floors. In contrast to conventional shower elements, the Fundo Ligno is adapted to the covering layer of wood and is just 20 mm thick in the border area. It therefore integrates wonderfully into the surface layer – without creating extra height and without time-consuming levelling measures.







## Fundo Ligno Point drainage on suspended timber floors




- 1 wedi Fundo Ligno flush to floor shower element for wooden beam joists
- 2 wedi Fundo drain integrated into the suspended timber floor
- 3 wedi building boards for constructing shower screens and for the cladding of adjoining areas
- 4 wedi 610 adhesive and sealant for the watertight adhesion of joints
- 5 wedi Tools reinforcement tape for reinforcing joints

#### The superimposed variant with an installation height of 20 mm

Alongside the embedded version, there is another option; installing the wedi Fundo Ligno floor element on the suspended timber floor. Additional floor levelling wedi building boards are used for this likewise simple installation. The joints here are sealed with wedi 610.



## Fundo Primo Easy Set Connecting substructure system for point drainage



- 1 wedi Fundo Primo shower element, in this case with central spot drainage
- 2 wedi Fundo drain in this case with a horizontal DN 50 drain
- 3 wedi Fundo Primo Easy Set the straightforward connecting substructure system in a complete set
- 4 wedi building boards for constructing shower screens and for the cladding of adjoining areas
- 5 wedi 610 adhesive and sealant for the watertight adhesion of joints
- 6 wedi Tools reinforcement tape for reinforcing joints

#### Height adjustment made easy

With the Fundo Primo Easy Set, flush to floor showers from the wedi Fundo range are quickly and easily brought to a suitable height. No laborious mortar and screed work is necessary. The overall installation height of the Fundo Primo Easy Set plus the Fundo element is 14 cm.





## Fundo Plano Linea 70 mm thin complete system



- 1 wedi Fundo Plano Linea shower element with integrated drainage technology (linear drainage)
- 2 wedi building boards for constructing shower screens
- 3 wedi Fundo sealing set for sealing of the perimeter of Fundo floor elements when connecting to adjacent surfaces
- 4 Optional: wedi Nonstep Pro Sound insulation mats for water noise insulation under wedi Fundo floor elements
- 5 Optional: wedi edge insulation strips Sound insulation and insulation for the area between wedi Fundo floor elements and the wall
- 6 wedi Fundo Plano Linea sealing pads for sealing the pipe connection

#### Linear drainage with integrated drain

wedi Fundo Plano Linea is the flat complete system for flush-to-floor showers with linear drainage with a total installation height of just 70 mm including pre-fabricated drain technology. The linear drainage is positioned very close to the wall and is available with either a short or a long channel. The precisely defined gradient is already incorporated into the floor element in the factory.





## Fundo Riolito neo Close-to-wall linear drainage



- 1 wedi Fundo Riolito neo the flush to floor shower element with close-to-wall linear drainage
- 2 wedi Fundo channel drain in this case with a horizontal DN 50 drain
- 3 wedi building boards for designing wall and niche solutions
- 4 wedi Fundo sealing set for sealing of the perimeter of Fundo floor elements when connecting to adjacent surfaces
- 5 Optional: wedi Nonstep Pro Sound insulation mats for water noise insulation under wedi Fundo floor elements
- 6 Optional: wedi edge insulation strips Sound insulation and insulation for the area between wedi Fundo floor elements and the wall

#### Design all along the line


wedi Fundo Riolito neo is a flush-to-floor shower element with a channel drain close to the wall which allows the shower water to run off in a slender line. The gradient required for this in each case is already incorporated into the floor elements and enables an almost jointless installation of large format tiles in a wide variety of thicknesses (5-25 mm).







## Fundo Riolito The classic type of linear drainage



- 1 wedi Fundo Riolito the shower element with linear drainage
- 2 wedi building boards for constructing shower screens and for the cladding of adjoining areas
- 3 wedi 610 adhesive and sealant for the watertight adhesion of joints
- 4 wedi Tools reinforcement tape for reinforcing joints

#### Quickly installed with confidence

The flush-to-floor Fundo Riolito and Fundo Riofino shower elements from wedi are also ideally suited for linear drainage on wooden surfaces. Exactly like installation on screed, with either a vertical or horizontal wedi system drain.



## Fundo Riolito Discreto visual wall drain



- 1 wedi Fundo Riolito the shower element with linear drainage
- 2 wedi Fundo Riolito Discreto the visual wall drain
- 3 wedi building boards as free-standing partition wall and for the cladding of wall surfaces
- 4 Optional: wedi Nonstep Pro Sound insulation mats for water noise insulation under wedi Fundo floor elements
- 5 Optional: wedi edge insulation strips Sound insulation and insulation for the area between wedi Fundo floor elements and the wall
- 6 wedi 610 adhesive and sealant for the watertight adhesion of joints
- 7 wedi Tools reinforcement tape for reinforcing joints
- 8 wedi Fundo sealing set for sealing of the perimeter of Fundo floor elements when connecting to adjacent surfaces

#### Design drain with the wow effect

Timeless design and entirely new design possibilities. The Fundo Riolito Discreto literally tops the Riolito neo and Riolito, as well as the Plano Linea. As a simple attachment element, this clever innovation creates a visually attractive wall drain. The attachment element can also easily be extended in all directions. Whether as seating, storage area or full front wall – the design possibilities are endless with this modular system component.



## wedi Shower-Kits The bathroom system in a box



- 1 wedi Fundo Primo shower element, in this case with offset spot drainage
- 2 wedi Fundo drain in this case with a horizontal DN 50 drain
- 3 wedi building boards for constructing shower screens and for the cladding of adjoining areas
- 4 wedi 610 adhesive and sealant for the water-tight adhesion of joints
- 5 wedi Tools reinforcement tape for reinforcing joints
- 6 wedi Tools sealing tape for secure sealing of corner, connecting and butt joints and intersections
- 7 wedi Tools more set components such as mounting plates, dowels, insulating board discs and self-tapping screws


#### Complete set for a flush-to-floor corner shower

The wedi shower kit is a complete set for creating a flush-to-floor corner shower. Handily packaged in just a single box, it contains all of the materials which are required for a watertight corner shower: a reliable floor construction consisting of a wedi floor element and the corresponding system drain, a watertight wall solution in the form of the wedi building board and the appropriate sealing and installation accessories.

- Complete set with perfectly coordinated system components
- 100 % watertight throughout the system
- Extremely safe, simple and quick to install
- Practical handling and secure transportation in just one box
- Optionally expandable with modular wedi system components such as bench or niche, for example



# Fundo Top The ready-to-fit surface for Fundo shower systems



### Fundo Top – Perfect fit

The wedi Fundo Top is a sleek, finished surface for Fundo floor elements and a high-quality alternative to traditional tiling. The one-piece, seamless element is made of a 6 mm thick, high strength mineral material with an elegant look and a very pleasant feel. The various Fundo Tops are perfect complements to the wedi Fundo Primo, Riolito neo and Plano floor elements. They are available in a variety of sizes and fit perfectly into any bathroom design in their four shades – white, beige, anthracite and grey.



anthracite








### Custom-fit installation, maximum safety!

wedi Fundo Top is a 100 % wedi system component and can be handled very easily and safely. Simply apply the wedi 610 adhesive and sealant to the already installed Fundo floor element according to the specified pattern shown below. Then lay the Fundo Top precisely on the floor element and weigh down evenly by placing weights on the protective cardboard included in the scope of delivery. Finally apply silicon to the transitions to wall and floor tiling.





### Products used

- 1 wedi Fundo Top Primo ready-to-fit surface for Fundo shower systems
- 2 wedi Fundo Primo shower element with central spot drainage
- 3 wedi building board for constructing shower screens/partitions
- 4 wedi 610 adhesive and sealant for the watertight adhesion of joints
- 5 wedi Fundo sealing set for sealing of the perimeter of Fundo floor elements when connecting to adjacent surfaces



### Fundo Primo

- Classic point drainage
- With either a vertical or a horizontal system drain
- For installation on screed and wood

### Fundo Riolito neo


- Close-to-wall linear drainage
- With either a vertical or a horizontal system drain
- For installation on screed and wood

### Fundo Ligno


- Point drainage especially for suspended timber floors
- With either a vertical or a horizontal system drain
- For installation in or on suspended timber floors


### Fundo Plano

- 65 mm thin complete system
- Permanently integrated wedi system drain
- Ideally suited to renovations




































Detailed installation instructions for all Fundo products can be found at www.wedi.eu










### Fundo processina

### wedi Fundo Simple, safe and quick

### Installation instructions and videos

Know how. The complete installation instructions for all wedi Fundo floor elements can easily be found online in the download area on **www.wedi.eu**. Our numerous and multilingual installation videos provide you with the appropriate moving images for the wedi system solutions on our YouTube channel at:

www.youtube.com/user/wediGmbH



## Channel covers and grates in a wide variety of designs

### High quality channel covers for the linear drainage

A close-to-wall linear drainage system already means a special design in every shower. The shower becomes a highlight as the linear drainage is enhanced with the new wedi channel covers. Available as a standard, exclusive or tileable design.



wedi Fundo standard channel cover



wedi Fundo tileable channel covers



wedi Fundo exclusive channel covers

### Exclusive grates for spot drainage

The new wedi grates convince with their design and quality. It is their precision detail that gives the shower its special touch. Whether in the round or square design, as a standard version or in solid stainless steel – wedi grates are the perfect solution for all designs and colours of tile.



wedi Fundo Fino 1.1



wedi Fundo Fino 2.1



wedi Fundo Fino 4.2




wedi Fundo Fino 5




wedi Fundo Fino 3

## First rate connections on both sides




### wedi Fundo tile and slope profiles

When installing flush to floor showers, it quickly becomes necessary to adapt the tiles to the slope profile of the floor element. Thanks to the wedi slope wedge, costly chamfering and cutting of the wall tiles is a thing of the past. The wedi Fundo tile and slope profiles are specially designed for the Fundo Riolito, Fundo Riolito neo and Fundo Plano Linea floor elements. They enable a high quality visual transition of the floor element slope profile to the even flooring or to a directly adjoining wall. The profiles are available in both a right and left version as well as in different heights.



### The technology Simply safe, simply easy

Functionality and safety play a key role in all of the wedi substructures. This is the very reason why tradesmen have been putting their faith in the unique quality of the wedi building boards for decades. They are thermally insulating, offer a variety of uses, allow for extension, and are both light and stable, as well as 100 % watertight.






### What is the construction height of which floor element?

When seeking the suitable floor element, one question is especially important: What is the construction height of the floor element? It is frequently the case that products are not promoted with the actual construction height, but with the shell dimension at the drain. What is actually required, however, is the highest point on the outer edge of an element. For this reason we always state the maximum height of the floor elements – the only mportant measure for you.

wedi flush to floor shower element + wedi Fundo drain = construction height



wedi Fundo floor elements	wedi Fundo drains	Installation height
wedi Fundo Ligno (installed flush to wooden joists)	Fundo vertical or horizontal drain, DN 50	0 mm
wedi Fundo Ligno (installed flush to wooden joists)	Fundo vertical or horizontal drain, DN 50	20 mm
wedi Fundo Primo	Fundo vertical drain, DN 50	40 mm
wedi Fundo Riolito neo, Riolito, Riofino	Fundo vertical drain, DN 50	50 mm
wedi Fundo Integro (integrated drain)	-	90 mm
wedi Fundo Plano (integrated drain)	-	65 mm
wedi Fundo Plano Linea (integrated drain)	-	70 mm
wedi Fundo Primo, Riolito neo, Riolito, Riofino	Fundo drain Minimax, DN 40	97 to 99 mm
wedi Fundo Primo, Riolito neo, Riolito, Riofino	Fundo horizontal drain, DN 50	130 mm

### Technical properties • Fundo Primo/Trollo/Borgo/Nautilo

Wheelchair load-bearing from minimum tile size	50 × 50 mm
Glass mosaic from 3 mm, minimum size	20 × 20 mm
Minimum foundation height depending on the drain: horizontal drain, DN 50	130 mm
Minimum foundation height depending on the drain: horizontal drain Mini Max, DN 40	97 mm
Minimum foundation height depending on the drains: vertical drain	40 mm
Surface slope (from outer edge of Fundo floor element to outer edge of drain opening) (exception: Fundo Nautilo, 28 mm surface slope)	18 mm
Waterproof tested	1.5 bar
Fire behaviour EN 13501	Е

### Technical properties • Fundo Ligno

Wheelchair load-bearing from minimum tile size	50 × 50 mm
Glass mosaic from minimum size	20 × 20 mm
Surface slope (from outer edge of Fundo floor element to outer edge of drain opening)	≥ 1.57 %
Waterproof tested	1.5 bar
Fire behaviour EN 13501	Е

### Drain attributes • Point drainage

Drainage rate Fundo drain Mini Max, horizontal, DN 40	0.54 l/s ; 32.4 l/min
Drainage rate horizontal drain (fixed in the element integrated) DN 40	0.50 l/s ; 30.0 l/min
Drainage rate Fundo drain, horizontal, DN 50	0.80 l/s ; 48.0 l/min
Drainage rate Fundo drain, vertical, DN 50	1.00 l/s ; 60.0 l/min
Drainage rate Fundo drain, vertical, DN 70	0.88 l/s ; 52.8 l/min

### Technical properties • Fundo Plano

Wheelchair load-bearing from minimum tile size	50 × 50 mm
Minimum foundation height	65 mm
Surface slope (from outer edge of Fundo Plano floor element to outer edge of drain opening)	≥ 1.26 %
Frame with stainless steel grid (secured in the element)	136 × 136 × 8 mm
Stainless steel grid	132 × 132 mm
Extension frame	136 × 136 × 24.7 mm
Waterproof tested	1.5 bar

### Technical properties • Fundo Riolito neo/Riolito/Riofino

Wheelchair load-bearing from minimum tile size	50 × 50 mm
Glass mosaic from minimum size	20 × 20 mm
Minimum foundation height depending on the drain: horizontal, DN 50	130 mm
Minimum foundation height depending on the drain: horizontal, Mini Max, DN 40	99 mm
Minimum foundation height depending on the drain: vertical drain, DN 50	50 mm
Surface slope (from outer edge of Riolito neo/Riolito/Riofino floor element to outer edge drain opening)	15 mm
Fundo Riolito neo/Riolito/Riofino are available with channels in the following lengths	300 to 1100 mm
Waterproof tested	1.5 bar
Fire behaviour EN 13501	Е

### Drain attributes • Linear drainage

Drainage rate Fundo channel drain Mini Max, horizontal, DN 40	0.50 l/s ; 30.0 l/min
Drainage rate Fundo Plano Linea horizontal drain (fixed in the element integrated) DN 40	0.40 l/s ; 24.0 l/min
Drainage rate Fundo channel drain, horizontal, DN 50	0.80 l/s ; 48.0 l/min
Drainage rate Fundo channel drain, vertical, DN 50	1.10 l/s ; 66.0 l/min

### Technical properties • Fundo Plano Linea

Wheelchair load-bearing from minimum tile size	50 × 50 mm
Total assembly height incl. integrated drainage	70 mm
Surface slope (from outer edge of Fundo Plano Linea floor element to outer edge of drain opening)	≥ 1.19 %
Adjustment range for stainless steel covers	5 – 25 mm
The Fundo Plano Linea is available with channels in the following lengths	300 to 900 mm
Waterproof tested	1.5 bar

### Technical properties • Fundo Integro

Wheelchair load-bearing from minimum tile size	50 × 50 mm
Glass mosaic from 3 mm, minimum size	20 × 20 mm
Minimum foundation height	90 mm
Surface slope (from outer edge of Fundo Integro floor element to outer edge of drain opening)	≥ 1.5%
Frame with stainless steel grid (secured in the element)	120 × 120 × 4 mm
Stainless steel grid	115 × 115 mm
Extension frame	Ø 115 × 40 mm
Drainage rate	0.80 l/s ; 48.0 l/min

### Technical properties • wedi building board

Sound insulation value DIN EN ISO 140-3 (with 12.5 board thickness)	Rw,P 23 dB
Fire behaviour EN 13501	Е
Bending stress in reference to DIN 53293 (applies to wedi building board with 10, 12.5 and 20mm board thickness)	3900 kPa (average)
Tensile strength	0.28 N/mm <sup>2</sup>
Weight of wedi building board (1250 x 600 x 4mm) to wedi building board XXL (2500 x 1200 x 50mm)	2.7 Kg to 13.8 Kg
Linear coefficient of thermal expansion	0.02 mm/mk

### Technical properties • wedi building board Vapor

Vapour barrier (sanded epoxy resin vapour barrier)	1.5 mm
Equivalent air space thickness, sd value (epoxy resin vapour barrier)	283 m
Resistance to water vapour diffusion (µ) EN 12086	188571
Thermal conductivity EN 13164	0.036 W/mK
Fire behaviour EN 13501	Е

### Technical properties • Raw foam building board systems

Extruded polystyrene hard foam	XPS
Long-term compressive strength (50 years) ≤ 2% compression EN 1606	0.08 N/mm <sup>2</sup>
Compressive resistance or compressive strength at 10% compression EN 826	0.25 N/mm²
Associated module of elasticity EN 826	10-18 N/mm²
Thermal conductivity EN 13164	0.036 W/mK
Tensile strength EN 1607	0.45 N/mm <sup>2</sup>
Shearing resistance EN 12090	0.2 N/mm <sup>2</sup>
Shear modulus EN 12090	7 N/mm²
Bulk density EN 1602	32 kg/m³
Resistance to water vapour diffusion (µ) EN 12086	100
Water absorption under long-term immersion EN 12087	≤ 1.5 Vol%
Capillary action	0
Linear coefficient of thermal expansion	0.07 mm/mK
Temperature limits	-50/+75°C
Fire behaviour EN 13501	Е
Carbon dioxide propellant GWP value	1

### Thermal insulation values • wedi building board

Nominal thickness [mm]	Thermal resistance $1/\Delta^{-1}$ [m <sup>2</sup> × K/W]	U value <sup>2)</sup> [W/m² × K]
4	0.108	3.60
6	0.167	2.97
10	0.229	2.509
12.5	0.3	2.13
20	0.514	1.46
30	0.800	1.03
40	1.086	0.80
50	1.371	0.65
60	1.657	0.55
80	2.229	0.42
100	2.800	0.34

### Thermal insulation values • wedi building board Vapor

Nominal thickness [mm]	Thermal resistance 1/Δ <sup>1)</sup> [m² × K/W]	U value ²) [W/m² × K]
14	0.3	2.13
21.5	0.514	1.46
51.5	1.371	0.65

 $<sup>^{1)}</sup>$  When determining the thermal resistance  $^{1/\Delta}$ , thermal conductivity group 035 in accordance with DIN 4108 is taken as the basis for the thermal insulation.

<sup>2)</sup> When determining the U value, only wedi building board and heat transmission resistance  $1/\alpha_1$  and  $1/\alpha_2$  for external walls are taken into account. In specific applications, the existing masonry and other layers must also be included.

## So that every seal remains secure

### Adhesive and sealant

wedi 610 – As a multi-use single component adhesive and sealant, wedi 610 is especially suited to the water-tight joint sealing of building boards and other elements. In addition to this it also offers excellent resistance to weathering and chemicals and is free from solvents, silicone and PCP.



### wedi sealing set

The wedi sealing set contains a 2-part sealant and wedi Tools sealant tape/sealing corners for flexible joint sealing – the perfect amount for the installation of a Fundo floor element. The wedi tools sealing tape, inside and outside corners, which are also available separately consist of a TPE coated polypropylene fleece. It is suitable for the watertight connections of wedi products to non-system materials.



### wedi Tools sealing tape

wedi Tools sealing tape includes a TPE-coated polypropylene fleece. This sealing tape creates waterproof joints between wedi building boards; and wedi Fundo elements to other non-wedi materials, such as screed and plasterboard, etc.



### Sealing sheet

wedi Subliner Dry – a thin-layered, crack-bridging sealing sheet made from highly tear-resistant polyethylene foil which, thanks to its special layer of fleeced material on both sides, provides the optimum anchorage for tile-laying materials. Perfect for combining with the wedi system components, e.g. wedi Tools sealing tape. This product can be used in combination with ceramic tiles and slabs as well as with natural stone cladding for internal walls and floors to provide quick sealing for projects with a fixed date of completion. Tested and approved for the A0 area of use.




### Sealing and decoupling

wedi Subliner Dry & Flex – flexible, crack-bridging sealing and decoupling sheet made from highly tear-resistant polyethylene film. This product can be used in combination with ceramic tiles and slabs as well as with natural stone cladding for internal and external walls and floors to provide quick sealing for projects with a fixed date of completion. The special sheet provides improved tension compensation when sudden temperature changes occur. Tested and approved for the A0 and B0 areas of use.



### Sealing gaiters

The flexible and fleece laminated wedi sealing gaiters are suitable for the sealing of all pipes under ceramic flooring in shower and wet rooms. Available in nominal diameters of DN 15 - 35, DN 40 - 75 and DN 90 - 125, they always offer a reliable sealing solution for different sizes of lead-throughs and a wide variety of applications.



### wedi butyl tub sealing tape – optionally in a set with self-adhesive decoupling strips


The fleece laminated wedi Tools tub sealing tape consists of a TPE-coated polypropylene fleece equipped with butyl strips. It has good adhesion properties and is suitable for secure sealing of tubs and shower trays made from steel enamel, acrylic or similar materials. It is optionally available in a set with the self-adhesive decoupling strip which creates tension compensation between the tub and the adjoining wall.



## The latest generation of sound insulation

### wedi Nonstep Pro

The wedi Nonstep Pro is the ideal product for sound insulation of both the water impact and the footstep noise and perfectly suited for installation under wedi Fundo floor elements. It does not only comply with the minimum requirements but has also been successfully tested for compliance with increased sound insulation requirements. The extremely and permanently elastic material, consisting of a combination of rubber granulate/fibres with polyurethane binding agents, ensures optimum sound insulation and vibration damping, offers high mechanical resistance and is available with a thickness of 8 or 17 mm.






### wedi Nonstep Plan


The wedi Nonstep Plan sound insulation mats with a flexible mineral coating are used for decoupling underneath ceramic floor coverings, laminate or readyto-lay parquet.

The wedi Nonstep Plus sound insulation composite board consists of a 6 mm wedi building board

bonded in the factory to a 5 mm rubber mat, creating an overlap. It is used for decoupling under ceramic flooring, laminate or ready-to-lay parquet.

wedi Nonstep Plus






# The products High quality, varied and compatible


### Modular systems

Variety in the system means variety in the shower. Modular wedi systems are simply indispensable under the tiling. High-quality ceramic coverings require a completely secure surface underneath. For this reason, especially for use under tiles, tradesmen have been trusting wedi's unique quality for decades. 100% waterproof with 100% certainty – signed and sealed by wedi.



### **Building boards**

### **Building boards & prefabricated elements**




### wedi building board

1250 × 600 × 4 mm • 01-00-00/004 1250 × 600 × 6 mm • 01-00-00/006 1250 × 600 × 10 mm • 01-07-00/010

2500 × 600 × 4 mm • 01-02-50/004 2500 × 600 × 6 mm • 01-02-50/006

2500 × 600 × 10 mm • 01-00-00/010 2500 × 600 × 12,5 mm • 01-00-00/112 2500 × 625 × 12,5 mm • 01-00-00/012 2500 × 600 × 20 mm • 01-00-00/020 2500 × 600 × 30 mm • 01-00-00/030 2500 × 600 × 40 mm • 01-00-00/050 2500 × 600 × 50 mm • 01-00-00/050 2500 × 600 × 600 mm • 01-07-10/060 2500 × 600 × 80 mm • 01-07-10/080 2500 × 600 × 80 mm • 01-07-10/080 2500 × 600 × 80 mm • 01-07-10/080 2500 × 600 × 80 mm • 01-07-10/080

2600 × 600 × 10 mm • 01-00-00/610 2600 × 600 × 20 mm • 01-00-00/620 2600 × 600 × 30 mm • 01-00-00/630 2600 × 600 × 40 mm • 01-00-00/640 2600 × 600 × 50 mm • 01-00-00/650



### wedi building board XL & XXL

2500 × 900 × 12.5 mm · 01-00-00/912 2500 × 900 × 20 mm · 01-00-00/920 2500 × 900 × 30 mm · 01-00-00/930 2500 × 900 × 50 mm · 01-00-00/950 2600 × 1000 × 50 mm · 01-00-00/950 2600 × 1200 × 12.5 mm · 01-00-01/220 2500 × 1200 × 30 mm · 01-00-01/220 2500 × 1200 × 30 mm · 01-00-01/250 2500 × 1200 × 50 mm · 01-00-01/250



### wedi Bathboard

side panel: 1800 × 600 × 20 mm • 07-38-20/100 2100 × 600 × 20 mm • 07-38-20/101

head piece: 770 × 600 × 20 mm • 07-38-20/102



### wedi Bathboard Shower

900 × 200 × 20 mm • 07-38-30/001 900 × 300 × 20 mm • 07-38-30/002



### wedi I-Board

1245 × 1200 × 20 mm • 07-39-64/220

### Partition wall systems




### wedi Moltoromo straight wall segment

300 × 50 × 2600 mm • 07-64-49/003 600 × 50 × 2600 mm • 07-64-49/004



### wedi Moltoromo angled wall segment

300 × 300 × 2600 mm • 07-64-49/002



### wedi Moltoromo curved wall segment

424,3/123,1 × 50 × 2600 mm • 07-64-49/005 421,0/ 88,1 × 50 × 2600 mm • 07-64-49/006 414,1/ 75,6 × 50 × 2600 mm • 07-64-49/001



### wedi Moltoromo corner profile

200 × 200 × 2600 mm • 07-64-49/010




### wedi Moltoromo centered end profile

93.3 × 100 × 2600 mm • 07-64-49/008



### wedi Moltoromo lateral end profile


100 × 100 × 2600 mm • 07-64-49/009



### wedi building board Construct

Längs: 2500 × 600 × 20 mm • 01-07-09/020 2500 × 600 × 30 mm • 01-07-09/030 2500 × 600 × 50 mm • 01-07-09/050

Quer: 2500 × 600 × 20 mm · 01-07-08/020 2500 × 600 × 30 mm · 01-07-08/030 2500 × 600 × 50 mm · 01-07-08/050



### wedi building board Vapor

2500 × 600 × 12.5 mm • 01-07-13/112 2500 × 600 × 20 mm • 01-07-13/020 2500 × 600 × 50 mm • 01-07-13/050



### wedi Mensolo-L

150 × 150 × 2500 mm • 07-43-00/091 200 × 200 × 2500 mm • 07-43-00/092 300 × 300 × 2500 mm • 07-43-00/093 200 × 400 × 2500 mm • 07-43-00/094 150 × 150 × 2600 mm • 07-43-00/691 200 × 200 × 2600 mm • 07-43-00/692 300 × 300 × 2600 mm • 07-43-00/693 200 × 400 × 2600 mm • 07-43-00/694



### wedi Mensolo-U

150 × 300 × 150 × 2600 mm • 07-43-00/696 200 × 200 × 200 × 2600 mm • 07-43-00/695



### wedi Niches

454 × 654 × 110 mm • 07-43-15/410 554 × 854 × 110 mm • 07-43-15/411 372 × 572 × 82,5 mm • 07-43-15/420 472 × 772 × 82,5 mm • 07-43-15/421



### wedi Moltoromo straight duct segment

100 × 600 × 2600 mm • 07-64-49/007



### wedi Moltoromo angled duct segment

300 × 300 × 2600 mm • 07-64-49/011



### wedi Moltoromo curved duct segment

180 × 424,3 × 2600 mm • 07-64-49/012 150 × 421,0 × 2600 mm • 07-64-49/013 140 × 414,1 × 2600 mm • 07-64-49/014



### wedi Moltoromo installation set

2 x fixing blocks

2 x isn'ing block.
4 x soft pads
1 roll of self-adhesive joint reinforcement tape 25 m
1 cartridge of wedi 610 adhesive sealant
1 x installation instructions

07-64-49/015



### wedi Moltoromo wall - / door fixing set

2 x fixing strips 6 x nailed dowel

07-64-49/016

### **Building boards**

### Installation materials & sealing



wedi 610 adhesive sealant

310 ml

07-69-02/002



wedi Fundo sealing set

2.4 kg powder component 1.2 kg liquid component 10 m sealing tape 2 inside corners

07-37-96/000



wedi edge insulation strips

25 m × 150 mm × 5 mm • 01-12-55/006



wedi Tools reinforcement tape and reinforcement tape self-adhesive

reinforcement tape 25 m × 125 mm • 09-52-20/053 50 m × 600 mm • 09-52-10/052

reinforcement tape self-adhesive 25 m × 125 mm • 09-52-25/053 50 m × 600 mm • 09-52-15/052



wedi Tools sealing tape

10 m × 120 mm • 09-51-10/311 50 m × 120 mm • 09-51-10/352 50 m × 100 mm • 09-51-00/352



wedi Tools corners, fleece laminated

outside: 115 × 115 mm inside: 120 × 120 mm 09-51-30/001 09-51-35/001



wedi Subliner Dry sealing membrane

30 × 1 m • 09-51-10/332 5 × 1 m • 09-51-10/305



wedi Subliner Dry & Flex sealing and decoupling membrane

15 × 1 m • 09-51-10/315



wedi protective covering fabric

25 × 1 m • 08-46-00/100



### metal dowel, galvanised

100 pieces • 09-49-20/104

10 pieces • 09-49-22/114 100 pieces • 09-49-20/114

80 mm 10 pieces • 09-49-23/108 100 pieces • 09-49-20/108 200 mm 100 pieces • 09-49-20/122

110 mm 10 pieces • 09-49-22/111 100 pieces • 09-49-20/111



### metal dowel, stainless steel

140 mm 10 pieces • 09-49-41/114 100 pieces • 09-49-40/114 10 pieces • 09-49-41/108 100 pieces • 09-49-40/108

110 mm 10 pieces • 09-49-41/111 100 pieces • 09-49-40/111





### wedi Tools washer

35 mm, galvanised 10 pieces • 09-48-62/106 100 pieces • 09-48-60/106

35 mm, stainless steel 10 pieces • 09-48-61/239 100 pieces • 09-48-60/239



### wedi Tools sealing gaiter

120 × 120 mm • 09-51-20/050 150 × 150 mm • 09-51-10/361 250 × 250 mm • 09-51-10/362



### wedi butyl bathtub sealing tape

3600 × 120 mm • 09-51-10/360



### wedi butyl bathtub sealing tape + self-adhesive decoupling strips

3600 × 120 mm

09-51-10/363



### wedi Tools connector 90°

5 pieces • 09-53-03/191 100 pieces • 09-53-00/191



### wedi Tools connector wall

5 pieces • 09-53-03/192 100 pieces • 09-53-00/192



### wedi Tools connector 180°

5 pieces • 09-53-03/193 100 pieces • 09-53-00/193



### connector 180°

100 × 100 × 8 mm 400 × 50 × 15 mm

20-65-53/001



### wedi Tools cavity dowels set

screw: Ø 4,5 × 60 mm dowel: Ø 6,0 × 35 mm

20-65-53/004

### Flush to floor showers

### Point drainage



wedi Fundo Primo square, central drain

900 × 900 × 40 mm • 07-37-35/170 1000 × 1000 × 40 mm • 07-37-35/131 1200 × 1200 × 40 mm • 07-37-35/171 1500 × 1500 × 40 mm • 07-37-35/175



wedi Fundo Primo square, corner drain

900 × 900 × 40 mm • 07-37-36/170 1000 × 1000 × 40 mm • 07-37-35/531 1200 × 1200 × 40 mm • 07-37-36/171 1500 × 1500 × 40 mm • 07-37-36/175



wedi Fundo Primo rectangular, central drain

900 × 750 × 40 mm • 07-37-35/176 1200 × 900 × 40 mm • 07-37-35/174 1400 × 900 × 40 mm • 07-37-35/196 1500 × 900 × 40 mm • 07-37-35/196 1800 × 900 × 40 mm • 07-37-35/580 1400 × 1000 × 40 mm • 07-37-35/580 1500 × 1000 × 40 mm • 07-37-35/198



wedi Fundo Trollo floor element

Ø 1140 × 40 mm • 07-37-36/575



wedi Fundo Nautilo floor element, right entry

1890 × 1515 × 50 mm • 07-37-36/066



wedi Fundo Nautilo floor element, left entry

1890 × 1515 × 50 mm • 07-37-36/065



1100 × 2015 mm • 04-17-09/002



1100 × 2015 mm • 04-17-09/003



wedi Fundo Nautilo libero

1850 × 2015 × 1475 mm • 04-17-08/002

### Wood floor solutions



wedi Fundo Ligno square, central drain

900 × 900 × 20/41 mm • 07-37-32/011 1200 × 1200 × 20/41 mm • 07-37-32/012 1500 × 1500 × 20/41 mm • 07-37-32/013



wedi Fundo Ligno square, corner drain

900 × 900 × 20/41 mm • 07-37-32/021 1200 × 1200 × 20/41 mm • 07-37-32/023

▲ Upper side ◀ Lower side



wedi Fundo Ligno rectangular, offset drain

1200 × 900 × 20/41 mm • 07-37-32/022 1600 × 900 × 20/41 mm • 07-37-32/024





wedi Fundo Primo rectangular, offset drain

1200 × 900 × 40 mm · 07-37-36/174 1400 × 900 × 40 mm · 07-37-35/150 1600 × 900 × 40 mm · 07-37-35/151 1800 × 900 × 40 mm · 07-37-35/180 1800 × 900 × 40 mm · 07-37-35/180



### wedi Shower-Kit square, central drain

900 × 900 × 40 mm • 07-37-37/100

The bathroom system in a box: wedi floor element with suitable system drain, wall solution in the form of wedi building boards and suitable sealing and installation accessories



### wedi Shower-Kit rectangular, offset drain

1200 × 900 × 40 mm • 07-37-37/101

The bathroom system in a box: wedi floor element with suitable system drain, wall solution in the form of wedi building boards and suitable sealing and installation accessories



wedi Fundo Borgo corner drain

900 × 900 × 40 mm • 07-37-35/576 1000 × 1000 × 40 mm • 07-37-36/576





wedi Fundo Nautilo left entry

1850 × 2015 × 1475 mm • 04-17-08/000




wedi Fundo Nautilo right entry

1850 × 2015 × 1475 mm • 04-17-08/000



wedi Fundo Nautilo libero right entry

1850 × 2015 × 1475 mm • 04-17-08/002



Individual designs. Talk to us!

wedi Fundo Special floor elements

All of the shower floor elements can also be realised quickly and straightforwardly according to customer requirements regarding their format, thickness and drain position.

### Flush to floor showers

### **Drain** grates



wedi Fundo Fino 1.1 / 1.3 drain grate, stainless steel incl. plastic frame

wedi Fundo Fino 1.1 115 × 115 × 5 mm

Also available as a screwable version

67-68-00/033

67-68-00/035



wedi Fundo Fino 2.1 / 2.3 drain grate, stainless steel incl. plastic frame

wedi Fundo Fino 2.1 115 × 115 × 5 mm

Also available as a 67-68-00/039

67-68-00/037

screwable version



wedi Fundo Fino 3.1 / 3.3 drain grate, stainless steel incl. plastic frame

wedi Fundo Fino 3.1 115 × 115 × 5 mm

Also available as a screwable version

67-68-00/040

67-68-00/042



wedi Fundo Fino 1.2 drain grate, stainless steel, round

Ø 115 × 5 mm • 67-68-00/034



wedi Fundo Fino 2.2 drain grate, stainless steel, round

Ø 115 × 5 mm • 67-68-00/038



wedi Fundo Fino 3.2 drain grate, stainless steel, round

Ø 115 × 5 mm • 67-68-00/041

### **Channel covers**

wedi Fundo channel cover standard, stainless steel

300 × 40 × 18 mm • 67-68-00/010 700 × 40 × 18 mm • 67-68-00/009

800 × 40 × 18 mm • 67-68-00/008

900 × 40 × 18 mm • 67-68-00/007

1100 × 40 × 18 mm • 67-68-00/006

wedi Fundo channel cover exclusive, solid stainless steel

300 × 40 × 21 mm • 67-68-00/001 700 × 40 × 21 mm • 67-68-00/002 800 × 40 × 21 mm • 67-68-00/003

### wedi Fundo channel cover tileable, stainless steel

 $300 \times 40 \times 18 \text{ mm} \cdot 67\text{-}68\text{-}00/011$   $700 \times 40 \times 18 \text{ mm} \cdot 67\text{-}68\text{-}00/012$   $800 \times 40 \times 18 \text{ mm} \cdot 67\text{-}68\text{-}00/013$   $900 \times 40 \times 18 \text{ mm} \cdot 67\text{-}68\text{-}00/014$   $1100 \times 40 \times 18 \text{ mm} \cdot 67\text{-}68\text{-}00/015$ 

### **Drains**



wedi Fundo vertical drain, DN 50 / DN 70

DN 50, square • 07-70-00/007 DN 50, round • 07-70-00/008 DN 70 • 07-70-00/010



wedi Fundo fire protection collar



wedi Fundo horizontal drain, DN 50

DN 50, square • 07-70-00/011 DN 50, round • 07-70-00/012



wedi Fundo drain Mini Max, DN 40

07-70-00/015



wedi Fundo Fino 4.1 drain grate, solid stainless steel incl. plastic frame

115 × 115 × 5 mm • 67-68-00/043



wedi Fundo Fino 5.1 drain grate, solid stainless steel incl. plastic frame

115 × 115 × 5 mm • 67-68-00/046



wedi Fundo Fino frame, stainless steel

120 × 120 × 10 mm • 07-71-00/003 120 × 120 × 6.2 mm • 07-71-00/004



wedi Fundo Fino 4.2 drain grate, stainless steel, round

Ø 115 × 5 mm • 67-68-00/044



wedi Fundo Fino 6.1 flat drain cover with frame, solid stainless steel, square

Ø 115 × 5 mm • 67-68-00/052



wedi Fundo Fino frame, stainless steel, round

Ø 120 × 9 mm • 07-71-00/001 Ø 120 × 2 mm • 07-71-00/002

### **Channel covers**

wedi Fundo Top Inlay with tileable channel cover, white

800 mm • 07-20-00/100

wedi Fundo Top Inlay with tileable channel cover, beige

800 mm • 07-20-00/200

wedi Fundo Top Inlay with tileable channel cover, grey

800 mm • 07-20-00/400

wedi Fundo Top Inlay with tileable channel cover, anthracite

800 mm • 07-20-00/300



wedi Fundo channel drain vertical, DN 50

07-75-00/002



wedi Fundo channel drain horizontal, DN 50

07-75-00/001



wedi Fundo channel drain Mini Max horizontal, DN 40, extra flat

07-75-00/003

### Flush to floor showers

### Linear drainage • Riolito



wedi Fundo Riolito square, drain at the side

900 × 900 × 50 mm • 07-37-37/303 1000 × 1000 × 50 mm • 07-37-37/308 1200 × 1200 × 50 mm • 07-37-37/304



wedi Fundo Riolito square, short channel, drain at the side

------

900 × 900 × 50 mm • 07-37-37/307



wedi Fundo Riolito rectangular, drain at the side

1200 × 800 × 50 mm • 07-37-37/301 1200 × 900 × 50 mm · 07-37-37/301 1200 × 900 × 50 mm · 07-37-37/305 1200 × 1000 × 50 mm · 07-37-37/302 1400 × 900 × 50 mm · 07-37-37/302 1800 × 900 × 60 mm · 07-37-37/306 1600 × 1000 × 50 mm · 07-37-37/310

### Slope profiles • Riolito

wedi Fundo Riolito slope wedge, left-hand version, stainless steel V<sub>2</sub>A

1200 × 8 mm • 10-61-00/008 1200 × 10 mm • 10-61-00/010 1200 × 12.5 mm • 10-61-00/012

1600 × 8 mm • 10-63-00/008 1600 × 10 mm • 10-63-00/010 1600 × 12.5 mm • 10-63-00/012

1800 × 8 mm • 10-65-00/008 1800 × 10 mm • 10-65-00/010 1800 × 12.5 mm • 10-65-00/012

### wedi Fundo Riolito slope profile wall, left-hand version, stainless steel V<sub>2</sub>A

1200 × 8 mm • 10-62-00/008 1200 × 10 mm • 10-62-00/010 1200 × 12.5 mm • 10-62-00/012

1600 × 8 mm • 10-64-00/008 1600 × 10 mm • 10-64-00/010 1600 × 12.5 mm • 10-64-00/012

1800 × 8 mm • 10-66-00/008 1800 × 10 mm • 10-66-00/010 1800 × 12.5 mm • 10-66-00/012

### Linear drainage • Riolito neo



wedi Fundo Riolito neo square, drain at the side

900 × 900 × 50 mm • 07-51-00/003 1000 × 1000 × 50 mm • 07-51-00/032 1200 × 1200 × 50 mm • 07-51-00/010



wedi Fundo Riolito neo square, short channel, drain at the side

900 × 900 × 50 mm • 07-51-00/031



wedi Fundo Riolito neo rectangular, drain at the side

1200 × 800 × 50 mm • 07-51-00/001 1200 × 900 × 50 mm • 07-51-00/004 1200 × 1000 × 50 mm • 07-51-00/008 1400 × 900 × 50 mm • 07-51-00/033 1800 × 900 × 60 mm • 07-51-00/035 1600 × 1000 × 50 mm • 07-51-00/034

### Finish and slope profiles • Riolito neo / Plano Linea

wedi Fundo Riolito neo / Plano Linea slope profile floor, left, stainless steel V<sub>2</sub>A

1200 × 8 mm • 10-71-00/008 1200 × 10 mm • 10-71-00/010 1200 × 12.5 mm • 10-71-00/012

1600 × 8 mm • 10-81-20/008 1600 × 10 mm • 10-81-20/010 1600 × 12.5 mm • 10-81-20/012

-----

wedi Fundo Riolito neo / Plano Linea slope profile wall, left, stainless steel  $V_2A$ 

1200 × 8 mm • 10-72-00/008 1200 × 10 mm • 10-72-00/010 1200 × 12.5 mm • 10-72-00/012

1600 × 8 mm • 10-82-20/008 1600 × 10 mm • 10-82-20/010 1600 × 12.5 mm • 10-82-20/012

1800 × 8 mm • 10-82-40/008 1800 × 10 mm • 10-82-40/010 1800 × 12.5 mm • 10-82-40/012

wedi Fundo Riolito neo / Plano Linea end profile

1000 × 21 mm • 10-73-00/001 1200 × 21 mm • 10-81-00/001

### Linear drainage • Riofino



wedi Fundo Riofino square, central drain

900 × 900 × 50 mm • 07-37-37/312 1000 × 1000 × 50 mm • 07-37-37/311 1200 × 1200 × 50 mm • 07-37-37/313



wedi Fundo Riofino rectangular, central drain

1200 × 900 × 50 mm • 07-37-37/314 1800 × 900 × 50 mm • 07-37-37/315



wedi Fundo Riolito Discreto Optical wall drain

800 × 180 × 76 mm • 07-37-38/200 900 × 180 × 76 mm • 07-37-38/201 1000 × 180 × 76 mm • 07-37-38/202

### wedi Fundo Riolito slope wedge, right-hand version, stainless steel $V_2A$

1200 × 8 mm • 10-61-10/008 1200 × 10 mm • 10-61-10/010 1200 × 12.5 mm • 10-61-10/012 1600 × 8 mm • 10-63-10/008 1600 × 10 mm • 10-63-10/010 1600 × 12.5 mm • 10-63-10/012

1800 × 8 mm • 10-65-10/008 1800 × 10 mm • 10-65-10/010 1800 × 12.5 mm • 10-65-10/012

### wedi Fundo Riolito slope profile wall, right-hand version, stainless steel V<sub>2</sub>A

1200 × 8 mm • 10-62-10/008 1200 × 10 mm • 10-62-10/010 1200 × 12.5 mm • 10-62-10/012 1600 × 8 mm • 10-64-10/008 1600 × 10 mm • 10-64-10/010 1600 × 12.5 mm • 10-64-10/012 1800 × 8 mm • 10-66-10/008 1800 × 10 mm • 10-66-10/010 1800 × 12.5 mm • 10-66-10/012



Individual designs. Talk to us!

wedi Fundo Special floor elements

All of the shower floor elements can also be realised quickly and straightforwardly according to customer requirements regarding their format, thickness and drain



------

wedi Fundo Riolito Discreto Optical wall drain

800 × 180 × 76 mm • 07-37-38/200 900 × 180 × 76 mm • 07-37-38/201 1000 × 180 × 76 mm • 07-37-38/202

### wedi Fundo Riolito neo / Plano Linea slope profile floor, right, stainless steel $V_2A$

1200 × 8 mm • 10-71-10/008 1200 × 10 mm • 10-71-10/010 1200 × 12.5 mm • 10-71-10/012 1600 × 8 mm • 10-81-30/008 1600 × 10 mm • 10-81-30/010 1600 × 12.5 mm • 10-81-30/012 1800 × 8 mm • 10-81-50/008 1800 × 10 mm • 10-81-50/010 1800 × 12.5 mm • 10-81-50/012

### wedi Fundo Riolito neo / Plano Linea slope profile wall, right, stainless steel $V_2A$

1200 × 8 mm • 10-72-10/008 1200 × 10 mm • 10-72-10/010 1200 × 12.5 mm • 10-72-10/012 1600 × 8 mm • 10-82-30/008 1600 × 10 mm • 10-82-30/010 1600 × 12.5 mm • 10-82-30/012 1800 × 8 mm • 10-82-50/008 1800 × 10 mm • 10-82-50/010 1800 × 12.5 mm • 10-82-50/012

### Individual designs.

All of the shower floor elements can also be realised quickly and straightforwardly according to customer requirements regarding their format, thickness and drain position. Talk to us!

### Flush to floor showers

### Complete systems



wedi Fundo Plano Linea short channel

900 × 900 × 70 mm • 07-37-36/608 1200 × 900 × 70 mm • 07-37-36/607



### wedi Fundo Plano Linea long channel

900 × 900 × 70 mm • 07-37-36/603 1200 × 800 × 70 mm • 07-37-36/600 1200 × 900 × 70 mm • 07-37-36/601 1200 × 1000 × 70 mm • 07-37-36/602



### wedi Fundo Riolito Discreto Optical wall drain

800 × 180 × 76 mm • 07-37-38/200 900 × 180 × 76 mm • 07-37-38/201 1000 × 180 × 76 mm • 07-37-38/202



square, central drain

900 × 900 × 65 mm • 07-37-35/600 1000 × 1000 × 65 mm • 07-37-35/601 1200 × 1200 × 65 mm • 07-37-35/602



### rectangular, offset drain

1400 × 900 × 65 mm • 07-37-35/605 1600 × 1000 × 65 mm • 07-37-35/606





### wedi Fundo Plano rectangular, central drain

1200 × 900 × 65 mm • 07-37-35/604 1200 × 900 × 65 mm • 07-37-35/603





wedi Fundo Integro square, central drain

900 × 900 × 90 mm • 07-59-00/004 1200 × 1200 × 90 mm • 07-59-00/007



wedi Fundo Integro rectangular, offset drain

1200 × 900 × 90 mm • 07-59-00/000 1400 × 900 × 90 mm • 07-59-00/001 1800 × 900 × 90 mm • 07-59-00/003 1600 × 1000 × 90 mm • 07-59-00/002



wedi Fundo Integro rectangular, central drain

1200 × 900 × 90 mm • 07-59-00/005 1200 × 900 × 90 mm • 07-59-00/006

# Flush to floor showers

# wedi Fundo Top Primo



wedi Fundo Top Primo, square, central drain

900 × 900 × 6 mm • 07-20-10/100



wedi Fundo Top Primo, square, central drain

1200 × 1200 × 6 mm • 07-20-10/103



wedi Fundo Top Primo, rectangular, central drain

1200 × 900 × 6 mm • 07-20-10/101



wedi Fundo Top Primo, rectangular, central drain

1800 × 900 × 6 mm • 07-20-10/104



wedi Fundo Top Primo, rectangular, offset drain



wedi Fundo Top Primo, rectangular, offset drain 1800 × 900 × 6 mm • 07-20-10/105



beige 07-20-10/200



beige 07-20-10/203



beige 07-20-10/201



beige 07-20-10/204



beige 07-20-10/202



beige 07-20-10/205



grey 07-20-10/400



grey 07-20-10/403



grey 07-20-10/401



grey 07-20-10/404



grey



grey

07-20-10/405



anthracite 07-20-10/300



anthracite 07-20-10/303



anthracite 07-20-10/301



anthracite 07-20-10/304



anthracite 07-20-10/302



anthracite 07-20-10/305

# wedi Fundo Top Plano




wedi Fundo Top Plano, square, central drain

900 × 900 × 6 mm • 07-20-30/100



wedi Fundo Top Plano, rectangular, central drain

1200 × 900 × 6 mm • 07-20-30/101



wedi Fundo Top Plano, rectangular, offset drain

1600 × 1000 × 6 mm • 07-20-30/102




beige 07-20-30/200



grey 07-20-30/400



anthracite 07-20-30/300





beige

07-20-30/201

beige 07-20-30/202



grey 07-20-30/401



anthracite 07-20-30/301



grey 07-20-30/402



anthracite 07-20-30/302

# wedi Fundo Top Riolito neo



wedi Fundo Top Riolito neo, rectangular

1200 × 900 × 6 mm • 07-20-20/100





grey 07-20-20/400



anthracite 07-20-20/300



wedi Fundo Top Riolito neo, rectangular

1800 × 900 × 6 mm • 07-20-20/102



wedi Fundo Top Riolito neo, rectangular 1600 × 1000 × 6 mm • 07-20-20/101



beige 07-20-20/202



beige 07-20-20/201



07-20-20/402



grey 07-20-20/401



07-20-20/302



anthracite 07-20-20/301

# Flush to floor showers

# Installation materials & sealing



wedi Fundo sealing set

2.4 kg powder component 1.2 kg liquid component 10 m sealing tape 2 inside corners

07-37-96/000



wedi 610 adhesive sealant

310 ml

07-69-02/002



wedi edge insulation strips

25 m × 150 mm × 5 mm • 01-12-55/006



wedi Tools reinforcement tape and reinforcement tape self-adhesive

reinforcement tape 25 m × 125 mm • 09-52-20/053 50 m × 600 mm • 09-52-10/052

reinforcement tape self-adhesive 25 m × 125 mm • 09-52-25/053 50 m × 600 mm • 09-52-15/052



wedi Tools sealing tape

10 m × 120 mm • 09-51-10/311 50 m × 120 mm • 09-51-10/352 50 m × 100 mm • 09-51-00/352



wedi Tools corners, fleece laminated

outside: 115 × 115 mm inside: 120 × 120 mm 09-51-30/001 09-51-35/001



wedi Subliner Dry sealing membrane

30 × 1 m • 09-51-10/332 5 × 1 m • 09-51-10/305



wedi Subliner Dry & Flex sealing and decoupling membrane

15 × 1 m • 09-51-10/315



wedi protective covering fabric

25 × 1 m • 08-46-00/100



# metal dowel, galvanised

100 pieces • 09-49-20/104

10 pieces • 09-49-22/114 100 pieces • 09-49-20/114

80 mm 10 pieces • 09-49-23/108 100 pieces • 09-49-20/108

200 mm 100 pieces • 09-49-20/122

110 mm 10 pieces • 09-49-22/111 100 pieces • 09-49-20/111



# metal dowel, stainless steel

140 mm 10 pieces • 09-49-41/114 100 pieces • 09-49-40/114 10 pieces • 09-49-41/108 100 pieces • 09-49-40/108

110 mm 10 pieces • 09-49-41/111 100 pieces • 09-49-40/111





▲ stainless steel ◀ galvanised

### wedi Tools washer

35 mm, galvanised 10 pieces • 09-48-62/106 100 pieces • 09-48-60/106

35 mm, stainless steel 10 pieces • 09-48-61/239 100 pieces • 09-48-60/239



# wedi Tools sealing gaiter

120 × 120 mm • 09-51-20/050 150 × 150 mm • 09-51-10/361 250 × 250 mm • 09-51-10/362



# wedi butyl bathtub sealing tape

3600 × 120 mm • 09-51-10/360



# wedi butyl bathtub sealing tape + self-adhesive decoupling strips

3600 × 120 mm

09-51-10/363



# wedi Tools connector 90°

5 pieces • 09-53-03/191 100 pieces • 09-53-00/191



### wedi Tools connector wall

5 pieces • 09-53-03/192 100 pieces • 09-53-00/192



# wedi Tools connector 180°

5 pieces • 09-53-03/193 100 pieces • 09-53-00/193



# connector 180°

100 × 100 × 8 mm 400 × 50 × 15 mm

20-65-53/001



# wedi Tools cavity dowels set

screw: Ø 4,5 × 60 mm dowel: Ø 6,0 × 35 mm

20-65-53/004

# Flush to floor showers / Wellness

# Sound insulation & decoupling



wedi Nonstep Pro sound insulation mat

600 x 600 x 8 mm • 01-12-55/000 900 x 5000 x 8 mm • 01-12-55/001 1200 x 5000 x 8 mm • 01-12-55/002 600 x 600 x 7 mm • 01-12-55/003 900 x 2500 x 17 mm • 01-12-55/004 1200 x 2500 x 17 mm • 01-12-55/005



wedi Nonstep Plan sound insulation mat

1196 × 590 × 6 mm • 01-12-20/000



wedi Nonstep Plus sound insulation composite panel

1200 × 600 × 12 mm • 01-12-00/000

# Prefabricated elements - Sanoasa benches and corner seat



wedi Sanoasa bench 1

900 × 380 × 454 mm • 07-64-47/020 1200 × 380 × 454 mm • 07-64-47/021



wedi Sanoasa bench 2 angled

900 × 380 × 454 mm • 07-64-47/022 1200 × 380 × 454 mm • 07-64-47/023



wedi Sanoasa bench 3 rounded

900 × 380 × 454 mm • 07-64-47/024 1200 × 380 × 454 mm • 07-64-47/025

# Prefabricated elements - Sanoasa Comoda benches



wedi Sanoasa Comoda bench with carrier element

Available in a variety of sizes and designs



wedi Sanoasa Comoda complete corner element, straight

Available in a variety of sizes and designs



wedi Sanoasa Comoda complete corner element, round


Available in a variety of sizes and designs

# Prefabricated elements • Sanoasa Bellina benches



wedi Sanoasa Bellina bench with carrier element

Available in a variety of sizes and designs



wedi Sanoasa Bellina complete corner element, straight

Available in a variety of sizes and designs



wedi Sanoasa Bellina complete corner element, round

Available in a variety of sizes and designs



wedi edge insulation strips

25 m × 150 mm × 5 mm • 01-12-55/006



wedi Subliner Flex decoupling membrane

30 × 1 m • 09-51-10/331




wedi Subliner Dry & Flex sealing and decoupling membrane

15 × 1 m • 09-51-10/315



wedi Sanoasa bench 4 straight, free-standing

1200 × 380 × 80 mm • 07-64-47/041



wedi Sanoasa corner seat element

600 × 300 × 100 mm • 07-37-84/302 800 × 400 × 100 mm • 07-37-84/402



wedi Sanoasa Comoda Finishing elements

Available in a variety of sizes and designs



wedi Sanoasa Comoda Finishing elements

Available in a variety of sizes and designs



wedi Sanoasa Comoda armrest

650 × 105 × 870 mm • 07-64-47/014



wedi Sanoasa Bellina Finishing elements

Available in a variety of sizes and designs



wedi Sanoasa Bellina Finishing elements

Available in a variety of sizes and designs



wedi Sanoasa Bellina armrest

550 × 105 × 650 mm • 07-64-48/014

# Wellness

# Prefabricated elements • Sanoasa Loungers



wedi Sanoasa Lounger 1 Available in a variety of sizes and designs



wedi Sanoasa Lounger 2 Available in a variety of sizes and designs



wedi Sanoasa Lounger 3 Available in a variety of sizes and designs

# Prefabricated elements • Sanbath bathroom furniture



wedi Sanbath Wave tub 1800 × 850 × 625 mm • 07-36-01/001



wedi Sanbath Cube tub



wedi Sanbath Wave wash basin 1800 × 850 × 625 mm • 07-36-07/001



1000 × 550 × 200 mm • 07-36-03/000



wedi Sanoasa Lounger 4

Available in a variety of sizes and designs



wedi Sanoasa Lounger 5

Available in a variety of sizes and designs



wedi Sanbath Cube wash stand

570 × 570 × 925 mm • 07-36-06/000



wedi Sanbath Wave shower unit

2500 × 1010,5 × 400 mm • 07-36-02/000



wedi Sanbath Cube shower unit

2200 × 400 × 850 mm • 07-36-05/000

# Customer-specific designs examples



Multi-sensory showers / shower systems Example 1



Multi-sensory showers / shower systems Example 2




Steam bath / hamam Example 1



Steam bath / hamam Example 2



Whirlpools / pools / plunge pools Example 1



Whirlpools / pools / plunge pools Example 2



Benches & loungers Example



Furniture & design elements Example



Fountain elements Example


# Every compartment design, every room concept, every wellness project

wedi manufactures customised solutions to customer request. For the planners, architects and builders of a wellness or hotel system, this means: From the design, planning and production of the individual components to the on-site installation, wedi is available to you as a key point of contact for all questions in every phase of the project.

As a systems provider and premium brand, we attribute considerable value to quality: Quality with the products and systems, quality with the employees and quality in the dialogue with you. We guarantee you a professional approach with every project and look forward to accepting your challenge.

### Talk to us!

Telephone: +49 2572 156-0
Fax: +49 2572 156-239
E-Mail: project@wedi.de
Web: www.wedi.eu



# We look forward to your visit www.wedi.eu

Whether you are a private or industrial customer, a tradesman, an architect or an investor – we guarantee you a professional approach with every project and look forward to accepting your challenge.


As a systems provider and premium brand, we attribute considerable value to quality: Quality with products and systems, quality with the employees, quality in the project management and quality in our discussions with you.

# Visit us at www.wedi.eu

The websites includes additional documents such as safety data-sheets, technical data-sheets, technical drawings, tender texts as well as wide range of attractive workmanship videos. Please do not hesitate to contact us if you have any questions, suggestions or require further information.



www.wedi.eu







- Australia
- Austria
- Belgium
- Bosnia Herzegovina
- Canada
- Croatia
- Czech Republic
- Denmark
- Estonia
- Finland
- France
- Germany
- Great Britain
- Greece

- Hungary
- Iceland
- Ireland
- Italy
- ItalyLatvia
- Lithuania
- Luxembourg
- Netherlands
- Norway
- Poland
- Portugal
- Romania
- RussiaSerbia
- Slovenia
- Spain
- Sweden
- Switzerland
- Turkey
- Ukraine
- USA

# ...wedi®

# wedi GmbH

Hollefeldstraße 51 48282 Emsdetten Germany

Telephone +49 2572 156-0 Fax +49 2572 156-133

info@wedi.de www.wedi.eu

